

# **USER MANUAL**

# **Model:**

CVG-10ARxl

Video Audio Distribution Amplifier



For maximum results, use Comprehensive Brand Premium High Resolution cables and connectors.

# **Contents**

1	Introduction	1
2	Getting Started	1
3	Overview	1
4	Your CVG-10ARxl Video Audio Distribution Amplifier	2
5	Installing on a Rack	4
6 6.1 6.2	Using the CVG-10ARxl Video Audio Distribution Amplifier Connecting a CVG-10ARxl Video Audio Distribution Amplifier Increasing the Outputs	5 5 6
7	<b>Technical Specifications</b>	8
Figu	ıres	
_	e 1: CVG-10ARxl Video Audio Distribution Amplifier e 2: Increasing the Outputs: Arranging a 1:30 Video Audio DA	2 7
Tab	les	
Table	1: Front Panel CVG-10ARxl Video Audio Distribution Amplifier Features 2: Rear Panel CVG-10ARxl Video Audio Distribution Amplifier Features 3: Technical Specifications of the CVG-10ARxl	2 3 8

#### 1 Introduction

Congratulations on purchasing your **CVG-10ARxl** *Video Audio Distribution Amplifier*. This product is ideal for:

- Audio video duplication studios
- Rental/staging, CCTV, and home theater use

The package includes the following items **CVG-10ARxl** *Video Audio Distribution Amplifier*, power cord and this user manual.

# 2 Getting Started

We recommend that you:

- Unpack the equipment carefully and save the original box and packaging materials for possible future shipment
  - Review the contents of this user manual

#### 3 Overview

The **CVG-10ARxl** is a state-of-the-art 1:10 video audio distribution amplifier using BNC connectors for composite video, and RCA connectors for unbalanced stereo audio signals. The **CVG-10ARxl** accepts a composite video input and distributes the signal to 10 identical outputs.

In particular, the CVG-10ARxl:

- Includes looping connectors for connecting to a local monitor, other acceptor, or for forming larger systems<sup>1</sup>
- Has a video bandwidth of 360MHZ, ensuring transparent performance with typical video and audio sources
- Can function as unbalanced stereo audio or balanced<sup>2</sup> mono audio (selected via an audio control button)
- Can output video signals that are DC or AC coupled for maximum flexibility (selected via a coupling button)
  - Has front panel video trimmer controls<sup>3</sup> for output level and cable

<sup>1</sup> For example, you can connect 3 CVG-10ARxl units to make a 1:30 video audio distribution amplifier (see section 6.2)

<sup>2</sup> Recommended for low signal transmission over long distances or in audio broadcasting studios for high quality signal recreation

<sup>3</sup> The video outputs are arranged in two blocks of 5 outputs (outputs 1 to 5, and outputs 6 to 10). Each block can be separately trimmed for output level and cable equalization (EQ.) thus achieving different compensations for different cable lengths

equalization (EQ.), as well as audio trimmer controls for left and right gain, with an enable / disable control button

Achieving the best performance means:

- Connecting only good quality connection cables, thus avoiding interference, deterioration in signal quality due to poor matching, and elevated noise levels (often associated with low quality cables)
- Avoiding interference from neighboring electrical appliances and positioning your **CVG-10ARxl** away from moisture, excessive sunlight and dust

# 4 Your CVG-10ARxI Video Audio Distribution Amplifier

Figure 1 and Tables 1 and 2 define the **CVG-10ARxl**:




Figure 1: CVG-10ARxl Video Audio Distribution Amplifier

Table 1: Front Panel CVG-10ARxl Video Audio Distribution Amplifier Features

#	Feature		Function
1	Power Switch		Illuminated switch supplying power to the unit
2	AUDIO	Left Gain Trimmer	Adjusts <sup>1</sup> the audio signal level for the left channel
3		BAL/ST Button	Pushing in selects balanced mono audio operation, releasing selects unbalanced stereo audio operation
4		Right Gain Trimmer	Adjusts <sup>1</sup> the audio signal level for the right channel
5		Enable/Disable Button	Pushing in enables audio gain trimmer control, releasing bypasses it disabling audio gain trimmer control
6	VIDEO	EQ. Trimmer	Adjusts <sup>1</sup> the video EQ. (equalization) compensation of outputs 6 to 10
7		LEVEL Trimmer	Adjusts <sup>1</sup> the video signal level of outputs 6 to 10
8		EQ. Trimmer	Adjusts <sup>1</sup> the video EQ. (equalization) compensation of outputs 1 to 5
9		LEVEL Trimmer	Adjusts <sup>1</sup> the video signal level of outputs 1 to 5

-

<sup>1</sup> Insert a screwdriver into the hole and carefully rotate it, to trim the level

Table 2: Rear Panel CVG-10ARxl Video Audio Distribution Amplifier Features

#	Feature	Function
1	VIDEO IN BNC Connector	Connects to the video source
2	VIDEO LOOP BNC Connector	For looping to increase output availability
3	Term Button	Pushing in selects 75Ω, releasing selects Hi-Z <sup>1</sup>
4	Coupling Button	Pushing in selects DC coupling <sup>2</sup> , releasing selects AC coupling (removing the DC offset of the input signal)
5	VIDEO OUTBNC Connectors	Connect to the video acceptors
6	AUDIO IN RCA Connectors	Connects to the stereo audio source
7	AUDIO LOOP RCA Connectors	For looping to increase audio output availability
8	AUDIO OUTPUTS RCA Connectors	Connect to the stereo audio acceptors
9	Power Connector with Fuse	AC connector enabling power supply to the unit

<sup>1</sup> For looping select Hi-Z

<sup>2</sup> Achieving the best linearity and signal fidelity

# 5 Installing on a Rack

This section describes what to do before installing on a rack and how to rack mount.

#### Before Installing on a Rack

Before installing on a rack, be sure that the environment is within the recommended range:					
Operating temperature range	+5 to +45 Deg. Centigrade				
Operating humidity range	5 to 65% RHL, non-condensing				
Storage temperature range	-20 to +70 Deg. Centigrade				
Storage humidity range	5 to 95% RHL, non-condensing				




When installing on a 19" rack, avoid hazards by taking care that:

- 1 It is located within the recommended environmental conditions, as the operating ambient temperature of a closed or multi unit rack assembly may exceed the room ambient temperature.
- 2 Once rack mounted, enough air will still flow around the machine.
- 3 The machine is placed straight in the correct horizontal position.
- 4 You do not overload the circuit(s). When connecting the machine to the supply circuit, overloading the circuits might have a detrimental effect on overcurrent protection and supply wiring. Refer to the appropriate nameplate ratings for information. For example, for fuse replacement, see the value printed on the product label.
- 5 The machine is earthed (grounded) in a reliable way and is connected only to an electricity socket with grounding. Pay particular attention to situations where electricity is supplied indirectly (when the power cord is not plugged directly into the socket in the wall), for example, when using an extension cable or a power strip, and that you use only the power cord that is supplied with the machine.

#### **How to Rack Mount**

To rack-mount a machine:

1 Attach both ear brackets to the machine. To do so, remove the screws from each side of the machine (3 on each side), and replace those screws through the ear brackets.



2 Place the ears of the machine against the rack rails, and insert the proper screws (not provided) through each of the four holes in the rack ears

#### Note that:

- Detachable rack ears can be removed for desktop use
- Always mount the machine in the rack before you attach any cables or connect the machine to the power

#### Using the CVG-10ARxI Video Audio Distribution Amplifier 6

You can connect:

- A single **CVG-10ARxl** unit (see section 6.1)
- Several CVG-10ARxl units to increase the number of outputs (see section 6.2)

### 6.1 Connecting a CVG-10ARxI Video Audio Distribution Amplifier

You can connect a single **CVG-10ARxl** *Video Audio Distribution Amplifier* unit as a 1:10 video audio DA, in which audio is unbalanced stereo audio (left and right) or balanced mono audio (+ and -).

To connect the CVG-10ARxI as a 1:10 video unbalanced stereo audio DA, do the following<sup>1</sup>:

- 1. Connect a video audio source (for example, a composite VCR) to the VIDEO IN BNC connector and to the left and right AUDIO IN RCA connectors.
- 2. Connect the 10<sup>2</sup> VIDEO OUT BNC connectors and the 10 left and right AUDIO OUTPUT RCA connectors to the video audio acceptors<sup>3</sup> 1 to 10.
- 3. Connect the power cord to the mains electricity.
- Push in the Term button to terminate the line to  $75\Omega$ . 4.
- 5. Release the BAL/ST button to select unbalanced stereo audio operation.
- Adjust<sup>4</sup> the video trimmer controls<sup>5</sup> for output signal level and/or cable compensation equalization level, if required.
- If audio control adjustment is required for left and/or right gain, push in Enable/Disable button, and then adjust<sup>3</sup> the trimmer controls.

4 Insert a screwdriver into the hole and carefully rotate it, to trim the level

<sup>1</sup> Switch OFF the power on each device before connecting it to your CVG-10ARxl, After connecting your CVG-10ARxl, switch on its power and then switch on the power on each device

<sup>2</sup> As required. Up to 10 outputs can be connected on the CVG-10ARxl. Not all outputs need to be connected

<sup>3</sup> For example, VCR units

<sup>5</sup> The video outputs are arranged in two blocks of 5 outputs (outputs 1 to 5, and outputs 6 to 10). Each block can be separately trimmed for output level and cable equalization (EQ.) thus achieving different compensations for different cable lengths

### 6.2 Increasing the Outputs

You can increase the number of outputs by interconnecting **CVG-10ARxl** units. The example in Figure 2 illustrates how to connect 3 units to increase the number of outputs from 10 to 30.

To form a 1:30 video and unbalanced stereo audio DA, do the following<sup>1</sup>:

- Connect a video audio source (for example, a composite VCR) to the VIDEO IN BNC connector and to the left and right AUDIO IN RCA connectors of the first CVG-10ARxl unit.
- 2. Connect the video LOOP BNC connector of the:
- First CVG-10ARxl unit to the VIDEO IN BNC connector of the second CVG-10ARxl unit
- Second CVG-10ARxl unit to the VIDEO IN BNC connector of the third CVG-10ARxl unit
- 3. Connect the left and right AUDIO LOOP RCA connectors of the:
- First CVG-10ARxl unit to the left and right AUDIO IN RCA connectors of the second CVG-10ARxl unit
- Second CVG-10ARxl unit to the left and right AUDIO IN RCA connectors of the third CVG-10ARxl unit
- 4. Connect the 10 VIDEO OUT BNC connectors and the 10 left and right AUDIO OUTPUT RCA connectors of the:
  - First CVG-10ARxl unit to the video audio acceptors<sup>2</sup> 1 to 10
  - Second CVG-10ARxl unit to the video audio acceptors<sup>2</sup> 11 to 20
  - Third CVG-10ARxl unit to the video audio acceptors<sup>2</sup> 21 to 30
- 5. On the first and second CVG-10ARxl units, release the Term button. On the third CVG-10ARxl unit, push in the Term button to terminate the line to  $75\Omega$ .
- 6. On each CVG-10ARxl unit:
  - Connect the power cord to the mains electricity
  - Release the BAL/ST buttons to select unbalanced stereo audio operation
  - Adjust<sup>3</sup> the video trimmer controls<sup>4</sup> for output signal level and/or cable

.

<sup>1</sup> Switch OFF the power on each device before connecting it to your CVG-10ARxl units. After connecting the CVG-10ARxl units, switch on their power and then switch on the power on each device

<sup>2</sup> For example, VCR units

<sup>3</sup> Insert a screwdriver into the hole and carefully rotate it, to trim the level

<sup>4</sup> The video outputs are arranged in two blocks of 5 outputs (outputs 1 to 5, and outputs 6 to 10). Each block can be separately trimmed for output level and cable equalization (EQ.) thus achieving different compensations for different cable lengths

## compensation equalization level, if required

• If audio control adjustment is required for left and/or right gain, push in the Enable/Disable buttons, and then adjust<sup>1</sup> the trimmer controls




Figure 2: Increasing the Outputs: Arranging a 1:30 Video Audio DA

7

<sup>1</sup> Insert a screwdriver into the hole and carefully rotate it, to trim the level

# 7 Technical Specifications

Table 3 includes the technical specifications:

Table 3: Technical Specifications of the CVG-10ARxl

INPUTS:	1 composite video, 1 looping, 1Vpp/75 $\Omega$ with termination switch on BNC connectors			
	2 audio, stereo or balanced mono, 2 looping, on RCA connectors			
OUTPUTS:	10 composite video, 1Vpp/75Ω on BNC connectors			
	10 audio, stereo or balanced mono, on RCA connectors			
MAX. OUTPUT LEVEL:	VIDEO: 1.6Vpp	AUDIO: 26.5 Vpp		
BANDWIDTH (-3dB):	VIDEO: 360 MHz	AUDIO: >100 kHz		
DIFF. GAIN:	0.07%			
DIFF. PHASE:	0.05 Deg.			
K-FACTOR:	<0.05%			
S/N RATIO:	VIDEO: 77dB	AUDIO: 87dB		
CONTROLS:	Front panel accessible trimmers for video level (-1.2dB to +6dB) and EQ. (0dB to +8.1dB), audio left and right control trimmers (0dB to +6dB), balanced/stereo selector switch and audio controls enable switch			
COUPLING:	VIDEO: DC/AC	AUDIO: AC		
AUDIO THD + NOISE:	0.023%			
AUDIO 2nd HARMONIC:	0.001%			
POWER SOURCE:	230 VAC 50 / 60Hz (115V U.S.A.), 4.7VA			
DIMENSIONS:	19-inch (W), 7-inch (D), 1U (H)			
WEIGHT:	2.1kg (4.7 lbs.) approx.			
ACCESSORIES:	Power cord			

8

<sup>1</sup> Specifications are subject to change without notice